


PARTS LIST

Accessory socket

Accessory socket
wire harness

Instruction label



2 Wire ties



Relay



Ground bolt, 6 mm



Fuse (10A)



Cushion tape

Under-hood fuse/relay
box label**TOOLS REQUIRED**

#2 Phillips screwdriver

Utility knife

Diagonal cutters

Ratchet


10 mm Socket

10 mm Open-end wrench

INSTALLATION


Before You Begin:

- Write down the customer's radio station presets; the radio memory will be erased when you disconnect the battery.
- If the radio has a coded theft protection circuit, be sure you have the anti-theft code before you disconnect the battery.




Installing the Accessory Socket

1. Disconnect the negative cable from the battery.
2. Remove the armrest pad and tool tray (with the tools) from the left rear side trim panel. Remove the jack concealed under the tool tray.




3. Remove the accessory socket hole cover from the rear side trim panel.

4. Locate the prewired harness blue-taped to the vehicle harness, then remove the two blue tapes to free the prewired harness. Pull the terminal/connector end of the prewired harness out of the rear side trim panel.
5. Separate the accessory socket assembly into the outer and inner sockets.
6. Slide the outer socket over the prewired harness.




7. Place the prewired harness back into the rear side trim panel, then pull the terminal/connector end out through the hole in the rear side trim panel.

8. Route the harness terminal through the instruction label, and connect the harness terminal to the inner socket terminal.




9. Insert the inner socket through the hole in the instruction label and rear side trim panel; then connect it to the outer socket by turning the outer socket in the direction shown.

10. Plug the remaining connector of the prewired harness onto the terminal on the outer socket. Make sure that the locking pawl on the connector is facing up.



11. Remove the adhesive backing from the instruction label, and adhere it to the rear side trim panel.


12. Secure the prewired harness with one wire tie and the cushion tape in the areas shown.




13. Reinstall all removed parts.

Routing the Accessory Socket Wire Harness


14. Remove the under-dash fuse box cover.



15. Above the under-dash fuse box, remove the bolt securing the white plastic connector holder; then install the relay from the kit with this bolt. Tighten the bolt securely.




16. Locate the 2-pin (green) connector blue-taped to the vehicle harness leading from the integrated control unit. Remove the blue tape to free the connector, and connect it to the 2-pin connector of the accessory socket wire harness.



17. Locate the other 2-pin connector blue-taped to the accessory socket wire harness, and remove the blue tape to free the connector. Plug the connector into the 2-pin connector of the vehicle harness.
18. Plug the 4-pin connector of the accessory socket wire harness into the relay.
19. Plug the 1-pin connector of the accessory socket wire harness into the No. 1 connector of the under-dash fuse box.
20. Route the ground terminal of the accessory socket wire harness as shown, and attach it to the instrument side panel with the 6 mm ground bolt from the kit.

21. Secure the accessory socket wire harness to the vehicle harness with one wire tie.




22. Reinstall the under-dash fuse box cover.

23. Open the hood, and remove the upper cover from the under-hood fuse/relay box.

24. Plug the 10A fuse from the kit into the fuse slot in the under-hood fuse/relay box. Attach the fuse label to the upper cover.

25. Reinstall the upper cover.



26. Check that all wire harnesses are routed properly and all connectors are plugged in.

27. Reinstall all removed parts.

28. Reconnect the negative cable to the battery.

29. Check that all lights work properly. Check operation of the accessory socket.

30. Enter the customer's radio anti-theft code if applicable, and reset the radio station presets.

31. Reset the clock.